


Care & Maintenance




Cleaning

Periodically clean the liquid filter (20) and the PP filter (29 & 29/1). Remove the filter and rinse it with running water to remove the clinging particles.

Avoid contamination when changing chemicals by running the fogger with clean water (or appropriate solvent) through unit and rinse tank thoroughly.

Periodically check the cleanliness of the air filter (11). If the motor does not breathe a sufficient quantity of clean air, the fogging operation will be inefficient and the motor could be overheated.

Contact AIROFOG USA or an authorized dealer for technical assistance



Artemis Bio-Solutions
1226 N Michael Drive
Suite C Wood Dale IL
60191 630.359.4090